



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1		Drive Cap	
1a	27362	Drive Cap - Metallic Purple	1
1b	27383	Drive Cap - Metallic Green	1
2		Upper Housing	
2a	27364	Upper Housing - Metallic Purple	1
2b	27382	Upper Housing - Metallic Green	1
3	27361	Switch Actuator	1
4	65828	Screw	2
5	64945	Rear Motor Frame	1
6	22267	Hanger Bail	1
7	21063	Switch Insulator	1
8	22681	Circuit Board	1
9	62647	Cord Set	1
10		Lower Housing	
10a	27363	Lower Housing - Metallic Purple	1
10b	27384	Lower Housing - Metallic Green	1
11	22423	Rear Housing Screw	2
12	22274	Front Housing Screw	2
13	64535	Lock Keeper	1
14	64537	Blade Lock	1
15	S63897	Hinge Assembly	1
16	27863	Blade Hinge Screw	2
17	64139	Blade Screw	2

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
18	64003	Blade Bracket	1
19	64027	Blade Guide	1
20	64013	Tension Spring	1
21	65806	Brush Spring	2
22	27847	Cargon Brush	2
23	65805	Brush Retaining Clip	2
24	21067	Small Bearing Cup	1
25	27198	Motor Retaining Clip	2
26		Field Assembly	
26a	22453	Field Assmeby - Super 2	1
26b	27352	Field Assembly - AGP2	1
27	27072	Armature Assembly (Includes #28)	1
28	27251	Metal Cam and Bearing Assembly	1
29	21068	Large Bearing Cup	1
30	65013	Front Motor Frame	1
31	S20651	Blade Drive Assembly	1
32	15766	Blade Drive Screw	2
33	17091	Self Adhesive Foam Pad	1

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use. If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S., attach a letter to outside of package explaining difficulty.