andis®

MODEL BGR+ CLIPPER
120 VOLT



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1	64806	Lower Housing	1
2	63846	Upper Housing	1
3	65267	Drive Cap	1
4	64902	Switch Button	1
5	64794	Switch Button Lock	1
6	64788	Switch Button Retainer	1
7	64527	Lock Ring	1
8	64508	Motor Battery Contacts	2
9	64944	Rear Motor Frame	1
10	65013	Front Motor Frame	1
11	21067	Small Bearing Mounting Ring	1
12	64507	Switch	1
13	57993	Screw, 5-18 x 0.375	6
14	64503	Copper Brush with Shunt	2
15	65806	Brush Spring	2
16	65805	Brush Retainer Clip	2
17	64514	Motor Frame Clip	2
18	64726	Armature Assembly	1
19	27251	Cam Assembly	1
20	64529	Magnetized Field Assemby	1
21	15766	Screw, 4-40 x 7/32	2
22	22319	Blade Drive Assembly	1
23	21068	Large Bearing Mounting Ring	1
24	64027	Blade Guide	1
25	64013	Tension Spring	1

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
26	64139	Blade Screw	2
27	64003	Blade Bracket	1
28	64784	O-Ring	1
29	27861	Screw, Blade Hinge	2
30	64606	Housing Screw	4
31		Hinge Assembly	1
31a	S21743	Hinge Assembly (Oster 76 & 89 Comp)	1
31b	S27091	Hinge Assy. (Oster 10,22, and 111)	1
32		Charger Assembly	
32a	64720	Charger Assembly UL	1
32b	64803	Charger Assembly CSA	1
33	64754	Foam Pad	1
34	64916	Oil Seal	1
35	64526	Positive Lead Wire (Not shown)	1
36	64725	Battery Pack	1

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use, If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.